

Chemlease® One FS EZ

Application

- 1.** Clean the mold 2 times with Chemlease Mold Cleaner EZ



Step 1:
Use 2 cotton cloths. One to apply and one for polishing off



Step 2:
Check with tape test

- 2.** Seal the mold with Chemlease 15 Sealer EZ (optional)



Step 3: Apply the sealer



Step 4:
Wait 15 – 20 seconds and polish of with a 2nd cloth

Leave to harden for at least 1 hour

- 3.** Applying Chemlease One FS EZ



Step 5: Just using a cotton cloth

Wait for 15 minutes and repeat step 5

OR

Spray on 3 to 5 layers without waiting !!



- 4.** Wait 30 minutes before use



Step 6:
Check with tape test

For further information please consult the product sheets on www.siliconesandmore.com