



Create Your Own Dildo Set

This Set includes all the supplies you need to make your own fun dildo.
Making your own dildo is quick and it's fun too!

Knead your own dildo from the plasticine. It is important that the model is slightly tapered so that later it can be easily removed from the alginate mold without breaking anything.

Mix the alginate 3D gel in the 1900 ml mixing cup. Use an alginate : water ratio of 1:3 so 100 grams of alginate with 300 grams of water.

Place the plasticine dildo in the alginate 3D gel.

Let the alginate 3D gel cure and remove the dildo of plasticine. Be careful or the alginate mold will break. Gently move the model back and forth to let air in.

Add your silicone dye to the silicone until you have a nice color, do this separately in the A component and in the B component, but make sure there is an equal amount of dye in both. use no more than 2% by weight of both components.

Mix the A component with the B component of the Silicone Addition Transparent 15 Quick set.
Pour the silicone into the mold of alginate.

After half an hour (at room temperature) you can remove the dildo from the mold.
Bake the dildo once for 2 to 3 hours in an oven at 100 °C to degas. Let the mold cool down!

Set contents:

- 1 x 500 grams Alginate 3D gel
- 1 x 550 grams Silicone Addition Transparent 15 Quick set
- 1 x 500 gram Plasticine for Addition Silicone
- 1 x mixing cup 1900 ml
- 1 x mixing cup 550 ml
- 1 x apron
- 1 x mixing spatula
- 1 x 50 grams silicone dye of your choice